REDRAGON

JABNS PRO

3 MODES CONNECTION LIGHT-WEIGHT GAMING MOUSE

Please scan here to download user manual

3 Modes Connection Light-weight Gaming Mouse
Operating Instructions

US UK

Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.


1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

Warm Tip: If needed, you can download the operating instructions and software for this product from our Redragon website https://www.redragonzone.com/

⚠ CAUTION:
Important Safety Note: For transportation and storage safety, the battery of this product is shipped at a reduced charge level. If you encounter insufficient battery upon first use, please fully charge the device before operation.

Button Instructions

1. Left button
2. Right button
3. Scroll wheel (Click as middle button)
4. Side button, defaulted forward
5. Side button, defaulted backward
6. DPI switch
7. BT pairing button
8. 2.4G/OFF/BT switch
9. USB receiver storage slot



Wired Connection

Connect the mouse to computer with USB cable in any connection mode, mouse will turn to wired connection mode.
The computer will recognize and configure the mouse automatically, the mouse will be charging the battery at same time.

2.4G wireless connection

Plug USB receiver into computer USB port, [BT/OFF/2.4G] switch on "2.4G", click any button, the computer will recognize and configure the mouse automatically

BT connection

[BT/OFF/2.4G] switch on "BT", press & hold [BT Pairing button] for 3s, LED indicator will flash in Blue, turn on the computer Bluetooth and searching for available device, select device name "BT 5.1 Mouse", the computer will recognize and configure the mouse automatically.
If auto-connection unsuccessful, or you want to connect a new device, press& hold button [BT Pairing button] for 3s, the mouse will enter paring status, repeat above operation to connect with new device.

DPI adjustment and Indication

Default DPI indicator color (LED under scroll wheel)
1. RED --------- 1000
2. BLUE -------- 2000
3. GREEN ------ 4000
4. YELLOW ---- 8000
5. CYAN ------- 13000
6. PURPLE ----- 26000

Report rates adjustment and indication.

The mouse supports adjust report rates (125Hz-250Hz-500Hz-1000Hz), press ③+④ buttons to adjust mouse report rates, LED indicator will flash in White as below:
125Hz ---- 1 time
250Hz ---- 2 times
500Hz ---- 3 times
1000Hz --- 4 times
Tip: Report rates adjustment is not available on BT connection mode.
For more adjustable functions, backlight setting and macro recording, please download & install mouse software to enable more possibility.

Power save mode & charging

When mouse is out of use for over 3min (wireless connection), it will enter power save mode, move or click any button to wake up.
When battery is low, the LED indicator will twinkling in Red, use USB cable connect mouse to computer to charging the battery, the LED indicator will steady on Red during charging, after fully charged the LED indicating current DPI level color.

Built-in Li-ion battery 1 unit.

⚠ Warning:Charging current: 5V ⎓ 1A max.

DO NOT use fast-charging adapter to recharge your mouse!

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
   (1) This device may not cause harmful interference, and
   (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The devicecan be used in portable exposure condition without restriction.

ISED WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licenceexempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteurexempt de licence contenu dans le présent appareil est conforme aux CNR-d'Innovation, Sciences et DéveloppementéconomiqueCanada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'appareil doit accepter tout brouillage radioélectrique subi, même si e brouillage est susceptible d'en compromettre le fonctionnement 'appareil numérique du ciem conforme

1. **Cleaning Instructions:** Before cleaning, always unplug the device from the computer's USB port. Clean the surfaces with a soft, dry cloth. For stubborn dirt, use a cloth that is slightly dampened with water. Do not use chemical agents or solvents. Ensure the devices are completely dry before reconnecting them.
2. **Ergonomic Health and Safety Guide:** Incorrect or prolonged use of computer equipment can lead to discomfort, fatigue, headaches and serious long-term injuries known as musculoskeletal disorders (MSDs). Please take relaxation breaks every 30-60 minutes.
3. **WARNING:** The product is not a toy. Please keep it out of reach of small children. The product contains small components that may pose a choking hazard.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.
DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.
DO NOT touch the battery fi material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.
DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.
DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

⚠ CAUTION

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

RU

Уважаемый пользователь


спасибо за выбор марки REDRAGON. С целью защиты ваших прав и для более качественного обслуживания мы просим учитывать наши условия гарантии.

1. В течение гарантийного периода гарантия распространяется на устранение повреждений, вызванных проблемами в электрической цепи. Повреждения, произошедшие по вине человека, такие как разборка, жесткие удары, погружение в воду, подключение к цепи с неномативным током или напряжением, а также ущерб, вызванный стихийными бедствиями, включая пожар, наводнение или землетрясение, в условия гарантии не включены.
2. Расходные детали (например, педаль для ног) и работы по замене запасных частей в гарантию не включены.

⚠ ВНИМАНИЕ:
Важное примечание по технике безопасности: В целях безопасности при транспортировке и хранении батарея данного изделия поставляется с пониженным уровнем заряда. Если при первом использовании вы обнаружите недостаток заряда батареи, пожалуйста, полностью зарядите устройство перед началом работы.

Описание кнопок

1. Левая кнопка
2. Правая кнопка
3. Колесо прокрутки (при нажатии работает как средняя кнопка).
4. Боковая кнопка, функция по умолчанию: вперед
5. Боковая кнопка, функция по умолчанию: назад
6. Переключатель разрешения DPI
7. Кнопка сопряжения по BT
8. Переключатель режимов 2.4G/OFF/BT
9.Отсек для хранения USB-ресивера



Проводное подключение

Подключите мышь к компьютеру с помощью USB-кабеля в любом режиме по включения, мышь перейдет в режим проводного подключения.
Компьютер автоматически распознает и настроит мышь, при этом начнется зарядка аккумулятора мыши.

Беспроводное подключение на частоте 2,4 ГГц

Вставьте USB-ресивер в USB-порт компьютера, переведите переключатель режимов [BT/OFF/2.4G] в положение "2.4G", нажмите любую кнопку, компьют ер выполнит распознавание и настройку мыши автоматически.

Подключение BT

Переведите переключатель [BT/OFF/2.4G] в положение "BT", нажмите и удер живайте кнопку сопряжения по BT в течение 3 секунд, светодиодный индик атор начнет мигать синим цветом. Включите на компьютере функцию BT и в ыполните поиск доступных устройств. Выберите имя устройства "BT 5.1 Mouse", после чего компьютер выполнит автоматическое распознавание и н астройку мыши.
Если автоматическое подключение выполнить не удалось или вы хотите под ключить новое устройство, нажмите и удерживайте кнопку сопряжения по BT в течение 3 сек, мышь перейдет в состояние сопряжения. После чего повт орите вышеуказанную операцию для подключения к новому устройству.

Настройка разрешения DPI и индикация

Цвета индикации режима DPI по умолчанию (светодиод под колесом прокру тки)
1. КРАСНЫЙ --- 1000
2. СИНИЙ ------- 2000

3. ЗЕЛЕНЫЙ ------- 4000
4. ЖЕЛТЫЙ -------- 8000
5. ГОЛУБОЙ ------- 13000
6. СИРЕНЕВЫЙ --- 26000

Настройка частоты опроса и индикация

Мышь поддерживает настройку частоты опроса [125 Гц-250 Гц-500 Гц-1000 Гц]. Для настройки частоты опроса нажмите кнопки ③+④, светодиод начнет мига ть белым цветом следующим образом:
125 Гц – 1 раз
250 Гц – 2 раза
500 Гц – 3 раза
1000 Гц – 4 раза
Совет: Функция настройки частоты опроса не доступна при подключении BT.

Для возможности более тонкой настройки функций, подсветки и записи мак росов вы можете загрузить и установить программное обеспечение мыши.

Режим энергосбережения и зарядка

Если мышь не используется более 3 минут (при беспроводном соединении), о на переходит в режим энергосбережения. Для пробуждения переместите мы шь или нажмите любую кнопку.
Когда аккумулятор разряжен, индикатор будет мигать красным цветом. Для з арядки мыши подключите ее с помощью USB-кабеля к компьютеру. Во время зарядки индикатор будет постоянно гореть красным, а после полной зарядк и индикатор начнет отображать текущий уровень DPI соответствующим цвет ом.

⚠ Предупреждение: Ток зарядки: макс. 5В⎓2А

Встроенный литий-ионный аккумулятор – 1 шт.

Часто задаваемые вопросы

1. Если мышь не реагирует,убедитесь, что она корректно подключена к соответствующему компьютеру через USB-порт, или попробуйте подключить ее через другой USB-порт.
2. Если курсор перемещается медленно или рывками, попробуйте использовать его на другой поверхности. Темные, загрязненные, неровные или яркие поверхности могут влиять на производительность мыши. При работе с мышью настоятельно рекомендуется использовать коврик.

REDRAGON

0.25-2.5 W USB PD

RoHS

ANATEL 03980-14-16556

型号	红龙M818-PRO 4087		备注：尺寸：L100*W100mm 材质：80g书写纸，风琴折页，正反印 印刷：单色				
名称	说明书(英+俄)						
日期	2026-8-21						
页码	1 OF 1		文件编号				
绘图	吴九香	审核	香敏琪	核准		版本	A.0

Easternlimes Tech